



3 +1 Wiring Reference



HARPER-WYMAN P/N: 6548G - Art Culinaire P/N: 65226005-3+1 (discontinued)

Input: (120v 60hz 4mA)

- The white/black stripe wire is the Line voltage from the terminal block (120v in - terminal L)
- The white wire is the Neutral from the terminal block (terminal N)
- The yellow/green stripe wire is Ground from the terminal block (terminal G)
- The #2 wire goes to all 4 switches (120v out - terminal C)
- The #3 wire is the return from the gas oven switch only (terminal R)
- The #1 wire is the return from the 3 left-hand burner switches (terminal M)

Output: (6 millijoule, 14kV - 3 Hz spark rate)

- The white or semi-clear mini-spade wire goes to the gas oven igniter electrode (terminal REIG)
- The 3 black or clear mini-spade wires go to the 3 top burners in no particular order (terminals 2, 4, & 5)



Art Culinaire | Lacanche USA, 1701 1st Street, Snohomish, WA 98290
www.frenchranges.com 1-888-222-2930