



## Control Panel Removal & Installation

- Shut off power to the range. Lift or remove the rangetop.
- Remove the [2] 8mm control panel mounting bolts at both ends inside of the side panels.







- Remove the phillips screws along the top of the control panel and all the handle knobs across the front.







 Remove the control panel ground strap [if applicable] and pull the control panel straight off the front. Take care not to damage the LED wires, label and unplug the LED connections. The control panel is now free to remove.







- The control panel venting flange slides just under the flashing located under the valves when reinstalling the control panel. Mind the oven control shafts when reinstalling. Install in reverse order.