



ranges of passion, form and function

Lacanche Burner Ignition Procedure & Use



Turn on main gas supply to range.

Depress handle & rotate burner valve handle anti-clockwise to “IGN” position.

Depress handle fully and wait for the burner’s thermocouple to heat up. Hold for 15-20 seconds *after flame has lit*. Igniters will spark (click) while handle is depressed.

Release handle and rotate burner valve handle to “HIGH” position.

Depress & rotate burner valve handle to the “LOW” position.

To rotate burner valve handle to “Off” position, slightly depress handle then move into “Off” position.

A reduced flowrate position identified by the “Low” mark produces the preset minimum burner power. This setting is adjustable behind the knob.

BURNER VALVE
HANDLE & DIAL